

Basic Color Changes – THESE ARE JUST SUGESTIONS FOR COLORS,
USE WHAT YOU LIKE.

44NL01

CC 1-GREEN
CC 2-PINK

44NL02

CC 1-GREEN
CC 2-GOLD

44NL03

CC 1-GREEN
CC 2-ROSE

44NL04

CC 1-PINK

44NL05

CC 1-PINK

69NL01

CC 1-GREEN
CC 2-YELLOW
CC 3-BLUE
CC 4-PINK

69NL02

CC 1-GREEN
CC 2-YELLOW
CC 3-GOLD

69NL03

CC 1-GREEN
CC 2-ROSE
CC 3-CREAM
CC 4-BLUE

69NL04

CC 1-PINK
CC 2-GREEN
CC 3-MAUVE

69NL05

CC 1-PINK

=====

Delicate Fancy Necklines

These are lovely light airy designs with few thread changes to help them
stitch out faster.

We will begin by printing a paper template of our design to use for placement and
centering.

Many embroidery software programs allow you to print templates. Contact your
embroidery machine dealer to see if there is any special software that is needed
to load the designs.

Once the template has been printed, trim around the design template.

Trim around the inside neck part of the template so you can see better where to
place it around the neck of the shirt.

Also fold the template in half so once you have it in position you can fold the top
over to mark the shirt.

Lay the T-shirt flat, and place the template on top of the shirt around the neck
where you think it looks the best and then using an air-erase pen (or other

marking tool), mark the center point on the shirt by folding down the top portion of the template and then the horizontal (on both sides) and vertical axis point (center bottom).



You can also find the center of the shirt by measuring between the sleeve seams and divide by two.

Let's finish marking the shirt so that it can be hooped correctly. Draw lines to connect the axis and center points. Also, extend the vertical axis line onto the stabilizer and above the neckline.



To stabilize the shirt for embroidery, turn it inside out. Cut a piece of cutaway stabilizer or no show mesh a bit larger than your hoop.

Then, spray the stabilizer with a bit of adhesive, and smooth it onto the inside of the shirt, on the area to be embroidered. (I love using the temp spray but please remember do not use spray in your work room it is best to do it outside as even if you are using the box to spray, the glue becomes air born and will attach itself to one of many surfaces in your work room like your machine or thread that's sitting out and when the glue gets on the thread it will cause thread breaks or tension problems do to it having the residue on it.)



Turn the shirt right side out.

Place the outer hoop inside of the T-shirt with the tab facing the bottom of the shirt. Place the inner hoop on top, aligning the marks on the hoop with the lines on the fabric. Press the hoop in place.



Roll the excess shirt up around the hoop and clip it out of the way (we used hair clips).



Attach the hoop to the machine and load the design. Move the hoop so that the needle is directly over the center point on the fabric.

Embroider the design.

When the design has finished, trim away the excess stabilizer on the back of the embroidery. Be sure to leave about 1/4 inch of excess around the edges of the design.

To add design to back

Add the coordinating accent design to the back of the shirt for a little extra pizzazz!

Place the design about 2 inches down from the center back of neck ribbing or to one side on back of shoulder and embroider it as you did with the front design.

You now have a fabulous Designer T-shirt with a light airy design stitched in a short amount of time!

If you have any problems e-mail me at e-mail below and I'll try to help.
Stitchart2@gmail.com

Hope you enjoy!!

Bonnie
Digitizer for SICK
www.stitchartdesigns.com
stitchart2@gmail.com