

INSTRUCTIONS FOR STITCHING OUT FREE STANDING CHRISTMAS ORNAMENTS

*****PLEASE NOTE*****THESE ARE NOT FREE STANDING LACE*****

ORNAMENTS REQUIRE FABRIC & WATER SOLUABLE STABILIZER

VERY IMPORTANTTHE FIRST 3 OUTLINES THAT STITCH ARE NOT TO CORRECT COLOR, PLEASE STITCH THEM THE COLOR OF THE FINAL SATIN STITCH*****

THESE ORNAMENTS ARE TO BE STICHED ON WATER SOLUABLE STABILIZER AND FABRIC. USE ANY KIND OF FABRIC YOU LIKE, JUST MAKE SURE IT WILL MAKE A GOOD BASE FOR THE ORNAMENTS (WE USED FELT). IT DOESN'T MATTER WHAT COLOR THE FABRIC IS, AS THE FABRIC WILL NOT BE VISIBLE WHEN ORNAMENT IS COMPLETE.



1) HOOP *STABILIZER* ONLY

2) LAY FABRIC OVER HOOPED STABILIZER. **DO NOT HOOP THE FABRIC.** You can spray embroidery adhesive on the stabilizer to keep the fabric in place if you like. Attach hoop to machine.

3) STITCH OUT FIRST OUTLINE ONLY. **Please see note at beginning of instructions about thread color** Remove hoop from machine.



4) CAREFULLY TRIM AWAY FABRIC AROUND STITCH LINE. Once all fabric is trimmed away put the hoop back on the machine.



5) RESTART MACHINE AND STITCH THE NEXT TWO OUTLINES. ****Please see note at beginning of instructions about thread color**** Once you are done with the outlines the fabric will be securely attached to the stabilizer, now you are able to finish stitching.



6) When stitching is complete remove hoop from machine and follow manufactures instructions for dissolving the water soluble stabilizer. Use a hole-punch or a regular punch to make a hole in the fabric (if necessary) that is in the ring at the top of the ornament and insert a Christmas tree hook. And as always ENJOY!