

## Instructions for sewing the FSL-Emoji-With-Magnet Design



This design is to be stitched on a DOUBLE layer of water-soluble stabilizer, the fabric type, not the film type.

The Color Sequence Chart below shows the various color changes for the design. It is necessary to **change bobbin and needle thread to the color being sewn** as the design can be viewed from both sides.

### Color Sequence:



Printed by Generations(TM). Copyright 2002-2007. All Rights Reserved.

1. Hoop a DOUBLE layer of water-soluble stabilizer in a 4x4 inch embroidery hoop.
2. Transfer the design file (NLSEE2740-4x4) to embroidery machine.
3. Thread needle and bobbin with white thread (the Color Sequence Chart shows cream instead of white-this was done to make the lace base more visible, but should be stitched in white thread).
4. Sew #1 in the Color Sequence Chart. These stitches will create the lace base of the design.
5. Remove hoop and cut all thread tails on front and back of the hoop.
6. Change needle and bobbin thread to brown.
7. Return hoop to machine and sew #2 in the Color Sequence Chart. These stitches will create the emoji.
8. Remove hoop and cut all thread tails on front and back of hoop.
9. Change needle and bobbin thread to white, return hoop to machine and sew #3 in the Color Sequence Chart. These stitches will create part of the eyes and the mouth of the emoji.
10. Remove hoop and cut all thread tails on front and back of the hoop.
11. Change needle and bobbin thread to grey, return hoop to machine and sew #4 in the Color Sequence Chart. These stitches will create part of the magnet.
12. Remove hoop and cut all thread tails on front and back of the hoop.
13. Change needle and bobbin thread to red, return hoop to machine and sew #5 in the Color Sequence Chart. These stitches will create the remainder of the magnet.
14. Remove hoop and cut all thread tails on front and back of the hoop.

15. Change needle and bobbin thread to black, return hoop to machine and sew #6 in the Color Sequence Chart. These stitches will create the satin border around the magnet.
16. Remove hoop from machine and project from hoop.
17. Cut away all but ¼ inch of stabilizer from around the design.
18. Place design in warm water and swish several times to remove Most of the stabilizer.
19. Blot away most of the water from the design using paper towels. Lay flat to dry. Once dry, the design is completed.